

Natural Dark Spot Corrector - 1157

Ingredient	Function	Percent	Wgt (g)	Wgt (oz)	Vol (tsp.)
Phase A					
Distilled Water (aqua)		73.10	73.10	2.58	14.62
Glycerin (glycerin)		4.00	4.00	0.14	0.80
Xanthan Gum, Prehydrated (xanthan gum)		0.20	0.20	0.01	0.04
HE-Cellulose, Modified (hydroxyethylcellulose)		0.50	0.50	0.02	0.10
Phase B					
Macadamia Nut Oil (macadamia Integrifolia [Macadamia] oil)		2.00	2.00	0.07	0.40
CreamMaker Fluid (sorbitan laurate, polyglyceryl-4 laurate, dilauryl citrate)		2.00	2.00	0.07	0.40
Vitamin E Tocopherol (dl-alpha tocopherol)		0.20	0.20	0.01	0.04
Phase C					
Aloe Vera 10x Concentrate (aloe barbadensis)		0.50	0.50	0.02	0.10
SkinWhite BLE (Arctostaphylos uva-ursi leave extract, magnesium ascorbyl phosphate, glycerin, water)		5.00	5.00	0.18	1.00
SkinWhite Herb, Cert. Organic (water, glycerin, alcohol, Malva Sylvestris [Mallow] extract, Mentha Piperita [Peppermint] leaf extract, Primula Veris extract, Alchemilla Vulgaris extract, Veronica Officinalis extract, Melissa Officinalis leaf extract, Achillea Millefolium extract)		5.00	5.00	0.18	1.00
Edelweiss Extract (glycerin, water, Leontopodium alpinum [Edelweiss] extract)		2.00	2.00	0.07	0.40
Willow Bark Extract (glycerin, water, Salix Alba [Willow] bark extract)		1.50	1.50	0.05	0.30
Vitamin C THDA (tetrahexyldecyl ascorbate)		2.00	2.00	0.07	0.40
Caprylyl Glycol EHG (caprylyl glycol, ethylhexylglycerin)		1.00	1.00	0.04	0.20
Phenoxyethanol SA (phenoxyethanol, sorbic acid, caprylyl glycol)		0.80	0.80	0.03	0.16
Fragrance Clean Linen		0.20	0.20	0.01	0.04

Method

No heating required. Add 1-4) to the vessel first, mix well using a homogenizer or stick blender. Let hydrate for 20 minutes, mix again. Pre-mix phase B. Add phase A to phase B and blend well (homogenizer or stick blender). Add phase C to phase A/B, one ingredient at the time and blend well. Fill into airless treatment pumps or similar containers.

Properties

Quick absorbing gel-cream that leaves a protecting film on the skin. Contains oil and water soluble skin lighteners that work on different levels. For spot treatment or even skin tone. Use twice a day for several weeks/months. Skin will be sensitive to UV radiation, avoid the sun or use a sunscreen for protection.